

DESCRIPTION




HOW TO USE

Hold the scissors at 90° to the stand so that the blade is pointing in the same direction as the narrow end of the slot. Slide the scissors in until it is firmly gripped in an upright position.

KEY FEATURES

- Easy to use
- Rubber foot prevents sliding thereby increasing stability
- Provides a basic table top scissor at low-cost

RECOMMENDED FOR



RELATED PRODUCTS

PEG-1 - Right Hand Easi-Grip® with short round ended blade
PEG-1/L - Left Hand Easi-Grip® with short round ended blade
PEG-3 - Right Hand Easi-Grip® with short pointed ended blade
PEG-5 - Right Hand Easi-Grip® with long pointed ended blade
PEG-5/L - Left Hand Easi-Grip® with long pointed blade

Peta (UK) Ltd

Charles House, Park Farm, Kelvedon Road, Inworth, Colchester, CO5 9SH, England

Tel : +44 (0) 1376 573476 Fax : +44 (0) 1376 570023

E-mail : sales@peta-uk.com Internet : peta-uk.com